



A novel advanced oxidation technology that rapidly removes geosmin and MIB from water and significantly reduces Atlantic Salmon depuration time

Christopher Haughey, Terence P. Barry, Ramsey Kropp,
Kyle Woolever, and Steven T. Summerfelt

Introduction

- Atlantic salmon reared in RAS accumulate off-flavors
 - Primarily due to geosmin (GSM) and 2-methylisoborneol (MIB)
- Off-flavors must be purged from fish before they can be sold
- Current solution: Hold fish for up to two weeks in separate depuration tanks flushed continuously with fresh water
- Depuration represents dominant water consumption for RAS salmon farms (70-90% of total farm consumption)


Problems with Current Purging Approach

- Fish are not fed – they lose weight and value
 - Up to 4.2% biomass loss, per Freshwater Institute
- Large volumes of water are required
 - FI guidelines of ~1,000 Liters / kg for depuration





Exciton Advanced Oxidation Process (eAOP®)

A technology that uses germicidal UV light to activate a proprietary photocatalyst that can effectively destroy a wide variety of microbial and chemical contaminants in water, including GSM and MIB



eAOP[®]: How it Works



Multiple Mechanisms of Action

eAOP[®] chemical reactions

No.	Type:	Chemical Reaction:
1	Anode	$2Cl^- \rightarrow Cl_2 + 2e^-$
2	Anode	$Cl_{2(aq)} + H_2O \rightarrow Cl_{(aq)}^- + HClO + H^+$
3	Anode	$6HOCl + 3H_2O \rightarrow 2ClO_3^- + 4Cl^- + 12H^+ + \frac{3}{2}O_2 + 6e^-$
4	Anode	$6ClO^- + 3H_2O \rightarrow 2ClO_3^- + 4Cl^- + 6H^+ + \frac{3}{2}O_2 + 6e^-$
5	Anode	$2H_2O \rightarrow O_2 + 4H^+ + 4e^-$
6	Anode	$2OH^- \rightarrow O_2 + 2H^+ + 4e^-$
7	Anode	$6ClO^- + 3H_2O \rightarrow 2ClO_3^- + 4Cl^- + 6H^+ + \frac{3}{2}O_2 + 6e^-$
8	Anode	$h^+ + OH_{ads}^- \rightarrow OH^*$
9	Cathode	$O_2 + e^- \rightarrow O_2^{\bullet -}$
10	Cathode	$O_2 + 2e^- + 2H^+ \rightarrow H_2O_2$
11	Cathode	$H_2O_2 + Cl_2 \rightarrow 2Cl^- + 2H^+ + O_2$
12	Cathode	$2H_2O + 2e^- \rightarrow 2OH^- + H_2$
13	Bulk	$HOCl \rightarrow ClO^- + H^+$
14	Photolysis	$Cl^- + h\nu \rightarrow Cl^* + 1/2O_2$
15	Photolysis	$HOCl + h\nu \rightarrow Cl^* + OH^*$

- 1 UV photolysis
- 2 Photocatalysis
- 3 Electrolysis
- 4 Hydroxyl radical production
- 5 UV/peroxide AOP

Research Objectives

1


Test the effects of eAOP® on geosmin and MIB removal from depuration tanks at a commercial Atlantic salmon RAS facility

(Superior Fresh, Hixton, WI)


2

Determine if depuration times can be shortened using eAOP®

Experimental Depuration Setup



Exciton Mark III-30 Reactor – Prototype Used for Trial



Methods - Experiments

Chemical Spiking Experiments

- Spike 18m³ depuration tank with GSM and MIB (no fish present)
- Control: sample water before eAOP reactor turned on
- Experiment: sample water after the reactor is turned on

Depuration Experiment


- Transfer fish (~4 kg) from main RAS and split cohort evenly between two tanks
- Control Tank: standard depuration procedure
- Experimental Tank: continuous use of eAOP treatment
- Sample water and fish over 10-day depuration cycle

Methods - Analytical


- Sample analysis: Gas Chromatography / Mass Spectroscopy
- Water samples:
 - 40 mL, standard vials, preserved with sodium omadine
- Fish samples:
 - ~100g sample, taken from anterior dorsal portion of fillet




Chemical Spiking Experiment: Geosmin / MIB levels in water



Fish Trial: Geosmin levels in the water



Fish Trial: Geosmin levels in the fish



Conclusions



eAOP rapidly removes geosmin and MIB from water, including when fish are present




eAOP technology can be used to significantly reduce depuration times (40-50% faster) and/or water usage

Economics



By reducing depuration time by 40-60%, we calculate that RAS operators can save between \$0.12 and \$0.22 per kg of salmon produced (fish weight + water usage)

Farm Size (metric tons)	Annual savings
1,500	\$180 - \$330 thousand
10,000	\$1.2 - 2.2 million

Publication: Aquacultural Engineering




Ongoing Research – Depuration in Brackish Water





Ongoing Research – Commercial-scale RAS Salmon Farm (I)

Geosmin spiking and fish depuration experiments conducted at working RAS Salmon farm



Ongoing Research – Commercial-scale RAS Salmon Farm (II)

Geosmin spiking experiment conducted in ~64 m³ depuration tank at working RAS Salmon farm



Acknowledgments

Superior Fresh

- Steve Summerfelt, CSO
- Brandon Gottsacker, President
- Kyle Woolever, Aquaculture Manager

Exciton Clean

- Terence Barry, Chief Scientist
- Ramsey Kropp, Lead Innovator

USDA Agricultural Research Service

- Casey Grimm, Food Processing and Sensory Quality Research Chemist

Analytical Environmental Laboratory (AEL)

- Kent Crozier, Lab Manager

Contact Information




Chris Haughey

Exciton Clean, LLC

+1 (310) 800-6350

chris@excitunclean.com

Thank You



Exciton Clean Mark III-30 Reactor (Production Series)